


LifeFitness

Arctic Silver 90RW Recumbent Bike



Customer Support Services
PARTS MANUAL

ARCTIC SILVER 90RW
REFERENCES

90RW-0XXX-02
S/N CCK100000 and UP

OPERATION MANUAL	M051-00K39-A026
ACCESSORY TRAY KIT	AK39-00052-0004
HARDWARE BAG	GK39-00002-0008
POLAR UPGRADE KIT	GK39-00002-0001
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
COAX CABLE	AK32-00020-0001
CONNECTION BRACKET ASSEMBLY ASSEMBLY CONSISTS OF: 1) POWER CABLE 2) POWER/COAX INPUT BRACKET 3) F TYPE CONNECTOR	AK39-00093-0000 AK32-00078-0001 0K39-01087-0000 0017-00021-2846
SERVICE MANUAL	M051-00K39-A012

**NOTE: ADDING THE BOLT ON LCD SCREEN TO THE
90RW-0XXX-02 MAKES THE UNIT 90RER-0XXX-02.**


	Page
CONSOLE COMPONENTS	4
CONSOLE SUPPORT ASSEMBLY	5
SHROUDS, END CAP, CRANKARMS AND PEDALS	6
BELTS.....	7
RESISTOR ASSEMBLY	8
POWER CONTROL BOARD	9
ALTERNATOR W/PULLEY	10
CRANKSHAFT AND BEARING ASSEMBLY.....	11
INTERMEDIATE SHAFT AND BEARING ASSEMBLY.....	12
IDLER BRACKET ASSEMBLY.....	13
SEAT ASSEMBLY.....	14
SEAT BOTTOM ASSEMBLY.....	15
SEAT FRAME ASSEMBLY.....	16
SEAT PADS AND ACCESSORY TRAY.....	17
EXTRUSION ASSEMBLY.....	18
SEAT LOCKING ASSEMBLY.....	19
WHEEL AND LEVELER.....	20
CABLES.....	21

ARCTIC SILVER 90RW

Console Components

90RW-0XXX-02


S/N CCK100000 and UP



Console Assembly	Overlay/Bezel/Switch Assy.	Upper Overlay	Lower Overlay
AK63-00162-0001 Eng Met	AK63-00167-0001 Eng Met	0K63-01288-0001 Eng Met	0K63-01290-0001 Eng Met
AK63-00162-0003 Ger Met	AK63-00167-0003 Ger Met	0K63-01288-0003 Ger Met	0K63-01290-0003 Ger Met
AK63-00162-0004 Spn Met	AK63-00167-0004 Spn Met	0K63-01288-0004 Spn Met	0K63-01290-0004 Spn Met
AK63-00162-0006 Jap Met	AK63-00167-0006 Jap Met	0K63-01288-0006 Jap Met	0K63-01290-0006 Jap Met
AK63-00162-0007 Frn Met	AK63-00167-0007 Frn Met	0K63-01288-0007 Frn Met	0K63-01290-0007 Frn Met
AK63-00162-0008 Itl Met	AK63-00167-0008 Itl Met	0K63-01288-0008 Itl Met	0K63-01290-0008 Itl Met
AK63-00162-0009 Dut Met	AK63-00167-0009 Dut Met	0K63-01288-0009 Dut Met	0K63-01290-0009 Dut Met
AK63-00162-0010 Por Met	AK63-00167-0010 Por Met	0K63-01288-0010 Por Met	0K63-01902-0010 Por Met

ARCTIC SILVER 90RW
Console Support Assembly

90RW-0XXX-02
S/N CCK100000 and UP





ARCTIC SILVER 90RW

Shrouds, End cap and Pedals

90RW-0XXX-02


S/N CCK100000 and UP





ARCTIC SILVER 90RW
Resistor Assembly


90RW-0XXX-02
S/N CCK100000 and UP



ARCTIC SILVER 90RW
Power Control Board

90RW-0XXX-02
S/N CCK100000 and UP

Assembly Number - AK39-00022-0002



ARCTIC SILVER 90RW
Alternator w/Pulley Assembly

90RW-0XXX-02
S/N CCK100000 and UP

Assembly Number – AK63-00093-0000


Alternator Pulley
OK61-02500-0001

Alternator
0017-00009-0841

Locking Nut
0017-00103-0117

Washer
0017-00104-0044


Bolt
0017-00101-0956



ARCTIC SILVER 90RW
Crank Shaft and Bearing Assembly

90RW-0XXX-02
S/N CCK100000 and UP

Kit Number – GK63-00002-0006




ARCTIC SILVER 90RW

Intermediate Shaft and Bearing Assembly


90RW-0XXX-02

S/N CCK100000 and UP

Kit Number – GK63-00002-0007



Idler Bracket Assembly – AK63-00021-0000




ARCTIC SILVER 90RW

Seat Assembly

90RW-0XXX-02

S/N CCK100000 and UP




ARCTIC SILVER 90RW

Seat Assembly - Bottom


90RW-0XXX-02

S/N CCK100000 and UP



ARCTIC SILVER 90RW
Seat Frame Assembly

90RW-0XXX-02
S/N CCK100000 and UP




ARCTIC SILVER 90RW

Seat Pads and Accessory Tray

90RW-0XXX-02

S/N CCK100000 and UP




ARCTIC SILVER 90RW

Extrusion Assembly – AK39-00027-0006

90RW-0XXX-02

S/N CCK100000 and UP




ARCTIC SILVER 90RW

Locking Assembly – AK51-00053-0001

90RW-0XXX-02

S/N CCK100000 and UP




ARCTIC SILVER 90RW

Wheel and Leveler

90RW-0XXX-02

S/N CCK100000 and UP



ARCTIC SILVER 90RW

Cables

90RW-0XXX-02

S/N CCK100000 and UP

